

2?? ?? BIOS ????????????Advanced?????PCH-IO Configuration?????

Aptio Setup - AMI

Main Advanced Security Boot Save & Exit

- ▶ Connectivity Configuration
- ▶ CPU Configuration
- ▶ Power & Performance
- ▶ System Agent (SA) Configuration
- ▶ PCIE Configuration
- ▶ PCH-IO Configuration
- ▶ PCH-FW Configuration
- ▶ Thermal Configuration
- ▶ Trusted Computing
- ▶ Hardware Monitor
- ▶ Fan Speed Curve Configuration
- ▶ Watch Dog Configuration
- ▶ S5 RTC Wake Settings
- ▶ AMI Graphic Output Protocol Policy
- ▶ USB Configuration
- ▶ Network Stack Configuration
- ▶ NVMe Configuration

- ▶ Tls Auth Configuration

PCH Parameters

→+: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.22.1292 Copyright (C) 2024 AMI

3?? ???State After G3???S0 State????????????S5 State????????????????????????????????????S0 State???????

Aptio Setup - AMI

Advanced

PCH-IO Configuration

- ▶ SATA Configuration
- ▶ USB Configuration
- ▶ Security Configuration
- ▶ HD Audio Configuration

State After G3 [S5 State]

State After G3

- S0 State
- S5 State

Specify what state to go to when power is re-applied after a power failure (G3 state).

→+: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.22.1292 Copyright (C) 2024 AMI

