

??????

??????CPU????

??CPU????????????????????????????????BIOS??CPU??????????

????????????????????????????????????CPU??????????

??


CPU????????

????CPU??????????


- 1. ??????????????????logo???????Del???BIOS




2. ???Advanced???Hardware Monitor?




3. ???Smart Fan Function?



4. ?CPU Smart Fan Mode??CPU?????????Automatic Mode???



5. ?????????????????????



?Manual Mode?

????????????????????PWM????????0?255????????????

Advanced

Aptio Setup - AMI

CPU Smart Fan Mode

Manual PWM Setting

[Manual Mode]

127

CPU Smart Fan Mode Select

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.22.1293 Copyright (C) 2025 AMI

?Automatic Mode?

??

Advanced

Aptio Setup - AMI

CPU Smart Fan Mode

Fan off temperature limit

Fan start temperature limit

Fan full speed temperature limit

Fan start PWM

PWM SLOPE SETTING

[Automatic Mode]

30

35

90

80

[2 PWM]

CPU Smart Fan Mode Select

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.22.1293 Copyright (C) 2025 AMI


“ ??????????[Fan start PWM]????65????CPU???

?????????

- ?Fan off temperature limit????????????CPU????????????????????????????????30?
- ?Fan start temperature limit????????????CPU????????????????????????????35?
- ?Fan full speed temperature limit????????????CPU????????????????????????????90?
- ?Fan start PWM??CPU????????????80
- ?SLOPESETTING????????????CPU????????????????????????????????

?Full on Mode?

????????????????????



????????????????????CPU????????????????????